




AB8008

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
AB8008-SP-1	AA027000045	Housing	No	
AB8008-SP-2	AA027000046	Brush tube	No	
AB8008-SP-3	AA027000047	Brush Holder	No	
AB8008-SP-4	AA027C00048	Carbon Brush	No	
AB8008-SP-5	AA027000049	Brush Cover	No	
AB8008-SP-6	AA027S00050	Stator	No	
AB8008-SP-7	A1018002700	Bearing 80027	No	
AB8008-SP-8	AA027R00052	Rotor	No	

AB8008-SP-9	AA027000053	Roller	No	
AB8008-SP-10	A1018002900	Bearing 629 (80029)	No	
AB8008-SP-11	AA027000055	Right Handle	No	
AB8008-SP-12	AA027000056	Screw	No	
AB8008-SP-13	AA027000057	Capacitor	No	
AB8008-SP-14	AA027000058	Switch	No	
AB8008-SP-15	AA027W00059	Switch	No	
AB8008-SP-16	AA027000060	Cord Armor	No	
AB8008-SP-17	AA027000061	Left Handle	No	
AB8008-SP-18	AA027000062	Screw	No	
AB8008-SP-19	AA027000063	Cord Clamp	No	
AB8008-SP-20	AA027000064	Right Hood	No	
AB8008-SP-21	AA027000065	Air Duct Transformation	No	
AB8008-SP-22	AA027000066	Air Duct Connector	No	
AB8008-SP-23	AA027000067	Air Duct	No	

AB8008-SP-24	AA027000068	Leaf Spring	No	
AB8008-SP-25	AA027000069	Dust Bag Connector	No	
AB8008-SP-26	AA027000070	Tie	No	
AB8008-SP-27	AA027000071	Dust Bag	No	
AB8008-SP-28	AA027000072	Washer	No	
AB8008-SP-29	AA027000073	Fan	No	
AB8008-SP-30	AA027000074	Net	No	
AB8008-SP-31	AA027000075	Left Hood	No	
AB8008-SP-32	AA027000076	Hood Cover	No	
AB8008-SP-33	AA027000077	Screw	No	
AB8008-SP-34	A1002000001	Power cable 2M	No	

AB8008

