



AB4018

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
AB4018-SP-1	AA027000001	Wind Pipe	No	
AB4018-SP-2	AA027000002	Wind Pipe Ring	No	
AB4018-SP-3/9	AA027000003	Left/Right Wind Housing	No	
AB4018-SP-4	AA027000004	Tapping Screw	No	
AB4018-SP-5	AA027000005	Nut	No	
AB4018-SP-6	AA027000006	Fan	No	
AB4018-SP-7	AA027000007	Tapping Screw	No	
AB4018-SP-8	AA027000008	Back Plate	No	
AB4018-SP-10	AA027000010	Tapping Screw	No	
AB4018-SP-11	AA027000011	Pan Washer	No	

AB4018-SP-12	A1010608000	Bearing 608	No	
AB4018-SP-13	AA027R00012	Rotor	No	
AB4018-SP-14	A1010627000	Ball Bearing 627	No	
AB4018-SP-15	AA027000013	Tapping Screw	No	
AB4018-SP-16	AA027S00014	Stator	No	
AB4018-SP-17	AA027000015	Handle Cover	No	
AB4018-SP-18	AA027000016	Cord Clamp	No	

AB4018-SP-19	AA027W00017	Switch	No	
AB4018-SP-21	AA027000019	Motor Mounting	No	
AB4018-SP-22	AA027000020	Detail Label	No	
AB4018-SP-23	AA027000021	Logo Label	No	
AB4018-SP-24	AA027000022	Brush Holder	No	
AB4018-SP-25	AA027C00023	Carbon Brush	No	
AB4018-SP-26	AA027000024	Brush Cover	No	
AB4018-SP-28	AA027000026	Cord Jacket	No	
AB4018-SP-29	A1002000001	Power cable 2M	No	

AB4018-SP-30	AA027000027	Dust Bag Ass'Y	No	
--------------	-------------	----------------	----	---

AB4018

