


Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
ASG1061-SP-N.S	TS00000384	Nozzle set	No	
ASG1061-SP-N.S.P	TS00000385	Nozzle set with Package	No	
ASG1061-SP-N.S.	TS00001040	Nozzle set	No	
ASG1061-SP-N.A1.3	TS00002509	Needle nozzle assembly1.3m	No	
ASG1061-SP-N.A1.5	TS00002510	Needle nozzle assembly1.5m	No	
ASG1061-SP-N.A1.7	TS00002511	Needle nozzle assembly1.7m	No	
ASG1061-SP-N.A1.8	TS00002512	Needle nozzle assembly1.8m	No	

ASG1061-SP-N.A2	TS00002513	Needle nozzle assembly2.0m	No	
ASG1061-SP-N.A2.5	TS00002514	Needle nozzle assembly2.5m	No	
ASG1061-SP-C.B	TS00003367	Color Box	No	
ASG1061-SP-A.B	TS00003479	Accessory Bag	No	
ASG1061-SP-1	AK001000060	Adj.Screw	No	
ASG1061-SP-2	AK001000061	Adj.Knob	No	
ASG1061-SP-3	AK001000062	O-ring 2.5*2.1	No	
ASG1061-SP-4	AK001000063	Flat Washer	No	

ASG1061-SP-5	AK001000064	Air Valve Spring	No	
ASG1061-SP-6	AK001000065	Air Inlet Valve	No	
ASG1061-SP-7	AK001000066	Switch Spring	No	
ASG1061-SP-8	AK001000067	Switch washer	No	
ASG1061-SP-9	AK001000068	valve body	No	
ASG1061-SP-10	AK001000069	O-ring 8.5*1.2	No	
ASG1061-SP-11	AK001000070	Trigger Valve Seat	No	
ASG1061-SP-12	AK001000071	foam Washer	No	

ASG1061-SP-13	AK001000072	Cowhide Washer	No	
ASG1061-SP-14	AK001000073	leading screw	No	
ASG1061-SP-15	AK001000074	Oil Tank Cover	No	
ASG1061-SP-15-18	AK001000450	Air Cap Ass'y	No	
ASG1061-SP-16	AK001000075	Nut	No	
ASG1061-SP-17	AK001000076	Hex. Socket Bolt M10×1.25×	No	
ASG1061-SP-18	AK001000077	Piston Pin	No	
ASG1061-SP-19	AK001000078	Nozzle	No	
ASG1061-SP-20	AK001000079	Hex. Socket Bolt M10×45 (12	No	
ASG1061-SP-21	AK001000080	Aluminum Head	No	
ASG1061-SP-22	AK001000081	Hex. Socket Bolt M14×40 (12	No	

ASG1061-SP-23	AK001000082	small washer	No	
ASG1061-SP-24	AK001000083	holddown spring	No	
ASG1061-SP-25	AK001000084	big washer	No	
ASG1061-SP-26	AK001000085	Trigger pin I	No	
ASG1061-SP-27	AK001000086	Trigger pin II	No	
ASG1061-SP-28	AK001000087	Trigger	No	
ASG1061-SP-29	AK001000088	E-ring	No	
ASG1061-SP-30	AK001000089	Trigger washer	No	 
ASG1061-SP-31/32/33	AK001000090	Cup Body Ass'y	No	

ASG1061-SP-34	AK001000093	Fluid Inlet Connector	No	
ASG1061-SP-35	AK001000094	composite material needle	No	
ASG1061-SP-36	AK001000095	Needle Spring	No	
ASG1061-SP-37	AK001000096	cap	No	
ASG1061-SP-38	AK001000097	valve adjuster plug	No	
ASG1061-SP-39	AK001000098	screw	No	
ASG1061-SP-40	AK001000099	Adjusting cap	No	
ASG1061-SP-41	AK001000100	Adjusting Screw seat	No	
ASG1061-SP-42	AK001000101	Adjusting washer	No	

ASG1061-SP-43	AK001000102	adjusting plug	No	
ASG1061-SP-44	AK001000103	O-ring 6*2	No	
ASG1061-SP-46	AK001000105	Air Inlet Plug	No	
ASG1061-SP-47	AK001000106	wrench	No	
ASG1061-SP-48	AK001000107	Strainer	No	
ASG1061-SP-49	AK001000108	brush	No	
ASG1061-SP-50	AK001000109	O-ring 11.2*1.6	No	
ASG1061-SP-51	AK001000110	hex wrench	No	

