

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
CGSLI2068-SP-1	AAA52704501	Screw	No	
CGSLI2068-SP-2	AAA52002401	Jamb tooth support	No	
CGSLI2068-SP-3	AAA52704401	Nut M6	No	
CGSLI2068-SP-4	AAA40015801	Left side cover plate	No	
CGSLI2068-SP-5	AAA53600401	Tensioning mechanism	No	
CGSLI2068-SP-6	AAA53600501	Elastic ring	No	
CGSLI2068-SP-7	AAA52704601	Screw	No	
CGSLI2068-SP-8	AAA52002501	Metal plate	No	

CGSLI2068-SP-9	AAA50002201	Gear	No	
CGSLI2068-SP-10	AAA40015901	Hand guard	No	
CGSLI2068-SP-11	AAA40016001	Button	No	
CGSLI2068-SP-12	AAA52901101	Button spring	No	
CGSLI2068-SP-13/17	AAA40015501	Left/Right housing	No	
CGSLI2068-SP-14	AAA20002101	Gear box	Yes	
CGSLI2068-SP-15	AAA22001001	Switch	Yes	
CGSLI2068-SP-15/16/37	AAAC0000438	Controller	No	
CGSLI2068-SP-16/37	AAA21001701	Controller	No	

CGSLI2068-SP-18	AAA52700301	Screw ST3.5*16	No	
CGSLI2068-SP-19	AAA00000081	Filter screen 1	No	
CGSLI2068-SP-20	AAA40016501	Butterfly buckle	No	
CGSLI2068-SP-21	AAA21002301	Motor	Yes	
CGSLI2068-SP-22	AAA52002301	Motor bracket	No	
CGSLI2068-SP-23	AAA52711901	Self tapping screw	No	
CGSLI2068-SP-24	AAA52701701	Screw	No	
CGSLI2068-SP-25/29	AAA40022301	Oil pot Assy.	No	
CGSLI2068-SP-25-29	AAA40022301	Oil pot Assy.	No	
CGSLI2068-SP-30	AAA53600601	Saw chain	No	

CGSLI2068-SP-31	AAA52002601	Guide plate	No	
CGSLI2068-SP-32	AAA52901201	Torsion spring	No	
CGSLI2068-SP-33	AAA40015601	Saw chain baffle	No	
CGSLI2068-SP-34	AAA40016201	Adapter	No	
CGSLI2068-SP-35	AAA42001601	Rubber column	No	
CGSLI2068-SP-36	AAA53300802	Filter screen 2	No	
CGSLI2068-SP-38	AAA40015701	Display panel	No	
CGSLI2068-SP-39	AAA40016301	Plastic pressing plate	No	

CGSLI2068-SP-40	AAA52901301	Tubing spring	No	
-----------------	-------------	---------------	----	---

