

Spare Part No.	Part No.	Part Name	Easy Damage
CIWLI2040-SP-1	AAA52709402	Screw	No
CIWLI2040-SP-2	AAAC0000087	Cephalic shell	No
CIWLI2040-SP-2-21	AAAC0000447	Gear Box Assy	No
CIWLI2040-SP-3	AAAC0001050	Output shaft bushing	No
CIWLI2040-SP-4	AAAC0000089	Output shaft friction gasket	No
CIWLI2040-SP-5/6	AAAC0000090	Output shaft assembly	No
CIWLI2040-SP-7/8/9/10/11	AAAC0000091	Impact block assembly	No
CIWLI2040-SP-12	AAAC0000092	Planetary gear	Yes
CIWLI2040-SP-13	AAA53301701	Cylinder pin	No
CIWLI2040-SP-14	AAAC0000093	Spacer	No
CIWLI2040-SP-15	AAAC0000094	Spacer	No

CIWLI2040-SP-16	AAAC0000095	Planetary ring	No
CIWLI2040-SP-17	AAA50008801	bearing	No
CIWLI2040-SP-18	AAAC0000096	Ring	No
CIWLI2040-SP-19	AAAC0000097	Gear case	No
CIWLI2040-SP-20	AAA42403901	Gear box cooling hole pad	No
CIWLI2040-SP-21	AAAC0000098	Ring	No
CIWLI2040-SP-22/33	AAAC0000614	Left and right case	No
CIWLI2040-SP-22/33-F	AAAC0000107	Left and right case	No
CIWLI2040-SP-23/26/29/30	AAAC0000108	Stator and electric control ass	Yes

CIWLI2040-SP-23	AAAC0000101	Stator	No
CIWLI2040-SP-24	AAAC0000102	Rotor	Yes
CIWLI2040-SP-25	AAAC0000829	Push button	No
CIWLI2040-SP-26	AAAC0000110	Switch	No
CIWLI2040-SP-27	AAA40082101	Speed regulating cover plate	No
CIWLI2040-SP-28	AAA40083201	Lampshade	No
CIWLI2040-SP-29/30	AAAC0000104	PCB	No
CIWLI2040-SP-31	AAAC0000109	Rear cover	No
CIWLI2040-SP-32	AAAC0000106	Screws	No

Part Picture
















