








CGSLI20128

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
CGSLI20128-SP-GEAR	AAA50002009	Gear	No	
CGSLI20128-SP-G.B.C.A	AAA20005402	Gear box cover assy	No	
CGSLI20128-SP-1-2/21-22	AAA40013001	Left/Right Housing	No	
CGSLI20128-SP-3	AAA40013101	Knob	No	
CGSLI20128-SP-4/5	AAA40013201	Knob seat/Seat insert	No	
CGSLI20128-SP-6	AAA52703601	Large washer	No	
CGSLI20128-SP-7	AAA40013301	Knob	No	
CGSLI20128-SP-8	AAA40013401	Right cover plate	No	
CGSLI20128-SP-9	AAA53600101	Chain	No	
CGSLI20128-SP-10	AAA53600201	Guide plate	No	
CGSLI20128-SP-11	AAA50001801	Ratchet wheel	No	
CGSLI20128-SP-12	AAA40013501	Dust cover	No	
CGSLI20128-SP-13	AAA42001101	Rubber strip	No	
CGSLI20128-SP-14	AAA40013601	Cover plate	No	
CGSLI20128-SP-15	AAA42001201	Rubber column	No	


CGSLI20128-SP-16	AAA40014801	Oil pot	No	
CGSLI20128-SP-17	AAA50001901	Adjusting gear	No	
CGSLI20128-SP-18	AAA51300901	Chain adjusting knob	No	
CGSLI20128-SP-19	AAA51301001	Slide block	No	
CGSLI20128-SP-20	AAA53300501	Pin	No	
CGSLI20128-SP-23	AAA52001801	Positioning film	No	
CGSLI20128-SP-24	AAA60500901	Switch	No	
CGSLI20128-SP-25	AAA40013701	Panel	No	
CGSLI20128-SP-26/51	AAA21001601	Controller assembly	No	
CGSLI20128-SP-26	AAA53000701	Bearing	No	
CGSLI20128-SP-27	AAA52900901	Spring	No	
CGSLI20128-SP-28	AAA40013801	Button	No	
CGSLI20128-SP-29	AAA40013901	Trigger	No	
CGSLI20128-SP-30	AAA60500701	Power switch	No	
CGSLI20128-SP-31	AAA52002101	Bead flange	No	
CGSLI20128-SP-32	AAA52200601	Seat	No	
CGSLI20128-SP-32-34/36/3	AAA20005302	Gear box seat assy	No	
CGSLI20128-SP-33	AAA53000301	Bearing	No	
CGSLI20128-SP-34	AAA52002201	Bead flange	No	
CGSLI20128-SP-35	AAA50002001	Motor teeth	No	
CGSLI20128-SP-36	AAA50002101	Gear wheel	No	


CGSLI20128-SP-37	AAA60002003	rotor	No	
CGSLI20128-SP-38	AAA51000201	Shaft	No	
CGSLI20128-SP-39	AAA53000401	Bearing	No	
CGSLI20128-SP-40	AAA52200602	Lid	No	
CGSLI20128-SP-41	AAA52703701	Screw	No	
CGSLI20128-SP-42	AAA40014001	Worm gear	No	
CGSLI20128-SP-43	AAA52703801	Nut	No	
CGSLI20128-SP-44	AAA52001901	Platen	No	
CGSLI20128-SP-45	AAA00000067	Assembly	No	
CGSLI20128-SP-46	AAA40014101	Bracket	No	
CGSLI20128-SP-47	AAA60002002	stator	No	
CGSLI20128-SP-48	AAA52703901	Screw	No	
CGSLI20128-SP-49/50	AAA40014201	Left/Right baseboard	No	
CGSLI20128-SP-51	AAA21001601	Controller assembly	No	
CGSLI20128-SP-52/57-66	AAA40014601	Oil pot Assy	No	


CGSLI20128-SP-53	AAA53600301	Oil pump	No	
CGSLI20128-SP-54	AAA52704001	Screw	No	
CGSLI20128-SP-55	AAA52704101	Screw	No	
CGSLI20128-SP-56	AAA40014301	Left lid	No	
CGSLI20128-SP-67	AAA40014701	Proof	No	
CGSLI20128-SP-68	AAA40014401	Front baffle	No	
CGSLI20128-SP-69	AAA52901001	Spring	No	
CGSLI20128-SP-70	AAA40014501	Shank	No	
CGSLI20128-SP-71	AAA52002001	Baffle	No	
CGSLI20128-SP-72	AAA53000601	Bearing	No	
CGSLI20128-SP-73	AAA52702801	Screw	No	






















9


8










1


































41

2











53



54

56







55



