

HG200038

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
HG200038-SP-1	DD00001063	Screw ST2.9X16	No	
HG200038-SP-2/20	DD00001064	Left/Right Housing	No	
HG200038-SP-3	DD00001065	circlip	No	
HG200038-SP-4	DD00001066	rivet	No	
HG200038-SP-5	DD00001067	spring	No	
HG200038-SP-6	DD00001068	heating wire assembly	No	
HG200038-SP-7	DD00001069	Motor fixture	No	
HG200038-SP-8	DD00001070	Bolt M3x5	No	

HG200038-SP-10	DD00001071	Power Cord 2M	No	
HG200038-SP-11	DD00001072	Wind balde	No	
HG200038-SP-12	DD00001073	Bolt M2.5x5	No	
HG200038-SP-13	DD00001074	Motor holder	No	
HG200038-SP-14	DD00001075	Screw ST2.9X10	No	
HG200038-SP-15	DD00001076	Motor	No	
HG200038-SP-16	DD00001077	Switch button	No	
HG200038-SP-17	DD00001078	PCB	No	
HG200038-SP-18	DD00001079	Screw ST4.1X16	No	
HG200038-SP-19	DD00001080	anchorage	No	

HG200038



