






Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
FS3208-SP-1	AA010000001	foam plate	No	
FS3208-SP-2	AA010000002	screw M4*12	No	
FS3208-SP-3	AA010000003	Thin Plate	No	
FS3208-SP-4	AA010000004	O ring $\phi 71 * \phi 64.8 * 3.1$	No	
FS3208-SP-5	AA010000005	aluminum plate	No	
FS3208-SP-6	AA010000006	screw M4*8	No	

FS3208-SP-7	AA010000007	wire clip	No	
FS3208-SP-8	AA010000008	screw ST4*16	No	
FS3208-SP-9	AA010000009	holder plate	No	
FS3208-SP-10	AA010000010	Holder	No	
FS3208-SP-11	AA010000011	screw M5*14	No	
FS3208-SP-12	AA010000012	Washer5*15*2	No	
FS3208-SP-13	AA010000013	balance weight	No	

FS3208-SP-14	AA010000014	screw M4*12	No	
FS3208-SP-15	AA010000015	bearing gland	No	
FS3208-SP-16	A1016202000	Bearings 6202	No	
FS3208-SP-17	AA010000016	flat ring	No	
FS3208-SP-18	AA010000017	fan	No	
FS3208-SP-19	AA010000018	Screw ST4x16	No	
FS3208-SP-20	AA010000019	Screw ST4x16	No	
FS3208-SP-21	AA010000020	middle cover	No	
FS3208-SP-22	AA010000021	rear cover	No	

FS3208-SP-23	AA010W00022	Switch	No	
FS3208-SP-24	AA010000023	capacitance	No	
FS3208-SP-25	AA010000024	inluctance	No	
FS3208-SP-26	AA010000025	Housing	No	
FS3208-SP-27	AA010000026	Brush Holder	No	
FS3208-SP-28	AA010C00027	Carbon Brush	No	
FS3208-SP-29	AA010000028	Brush cap	No	
FS3208-SP-30	AA010S00029	Stator	No	

FS3208-SP-31	AA010000030	B screw ST4.2*45	No	
FS3208-SP-32	A1010627000	Ball Bearing 627-2Z	No	
FS3208-SP-33	AA010000031	small dust proof ring	No	
FS3208-SP-34	AA010R00032	Rotor	No	
FS3208-SP-36	AA010000034	flat pin ring10	No	
FS3208-SP-37	A1016000000	bearing 6000	No	

FS3208-SP-38	AA010000035	sleeve	No	
FS3208-SP-39	A1002000001	Power cable 2M	No	
FS3208-SP-40	DD00002637	WASHER $\varnothing 15.5(*28*0.5)$	No	
FS3208-SP-41	DD00002442	screw ST4*16	No	