

LM383

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
LM383-SP-1	AA042000001	cover	No	
LM383-SP-2	AA042000002	Motor Cap	No	
LM383-SP-3	AA042000003	Upper Fan	No	
LM383-SP-4	AA042000004	motor set	No	
LM383-SP-5	AA042000005	Deck	No	
LM383-SP-6	AA042000006	Flap	No	
LM383-SP-7	AA042000007	Wheel Cover	No	
LM383-SP-8	AA042000008	Wheel	No	
LM383-SP-9	AA042000009	Wheel Cover Board	No	
LM383-SP-10	AA042000010	Front Wheel Bracket	No	
LM383-SP-11	AA042000011	Rear Wheel Bracket	No	
LM383-SP-12	AA042000012	Pole Set	No	
LM383-SP-13	AA042000013	Height Adjust Handle	No	
LM383-SP-14	AA042000014	Height Adjust Lever	No	
LM383-SP-15	AA042000015	Fence	No	

LM383-SP-16	AA042000016	Ring	No	
LM383-SP-17	AA042000017	Underside Fan	No	
LM383-SP-18	AA042000018	Knife plate	No	
LM383-SP-19	AA042000019	Blade Screw	No	
LM383-SP-20	AA042000020	Grassbox Handle	No	
LM383-SP-21	AA042000021	Grassbox Cover	No	
LM383-SP-22	AA042000022	Lower Grassbox	No	
LM383-SP-23	AA042W00023	Switch	No	
LM383-SP-24	AA042000024	Upper Handle	No	
LM383-SP-25	AA042000025	Knob	No	
LM383-SP-26	AA042000026	Height Adjust Lever Clamp	No	

LM383-SP-27	AA042000027	Spring	No	
LM383-SP-28	AA042000028	Spindle	No	
LM383-SP-29	AA042000029	Height Adjust Spring	No	
LM383-SP-30	AA042000030	Shaft Clamp	No	
LM383-SP-31	AA042000031	Lower Handle	No	
LM383-SP-32	AA042000032	Self-Tapping Screw	No	
LM383-SP-33	AA042000033	Screw	No	
LM383-SP-34	AA042000034	Screw	No	
LM383-SP-35	AA042000035	Nut	No	
LM383-SP-36	AA042000036	Pin	No	
LM383-SP-37	AA042000037	Spring	No	
LM383-SP-38	AA042000038	Check Ring	No	
LM383-SP-39	AA042000039	Nut	No	
LM383-SP-40	AA042000040	Nut	No	
LM383-SP-41	AA042000041	Bolt	No	
LM383-SP-42	AA042000042	Baffle	No	

LM383-SP-43	AA042000043	Screw	No	
LM383-SP-44	AA042000044	Spring	No	
LM383-SP-45	AA042000045	Height Adjust Shaft	No	

LM383



