



ED4508

Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
ED4508-SP-1	AA007000021	screw M5*18	No	
ED4508-SP-2	AA007000022	Chuck	No	
ED4508-SP-3	AA007000023	Output Spindle	No	
ED4508-SP-4	A1016200000	6200RS bearing	No	
ED4508-SP-5	AA007000024	Circlip For Shaft	No	
ED4508-SP-6	AA007G00025	Gear	No	
ED4508-SP-7	A1010607000	BEARING 607	No	
ED4508-SP-8	A1010607000	BEARING 607	No	

ED4508-SP-9	AA007R00026	Rotor	No	
ED4508-SP-10	AA007C00027	Carbon Brush	No	
ED4508-SP-11/12	AA007000028	brush holder/brush holder ca	No	
ED4508-SP-13	AA007S00030	Stator	No	
ED4508-SP-14	AA007000031	Left Housing	No	
ED4508-SP-15	AA007W00125	Switch	No	
ED4508-SP-16	AA007000033	Cord Sleeve	No	
ED4508-SP-17	AA007000034	80 Outgoing Line	No	
ED4508-SP-18	AA007000035	110 Outgoing Line	No	
ED4508-SP-19	AA007000036	screw 4x16	No	

ED4508-SP-20	AA007000037	Right Housing	No	
ED4508-SP-21	A1002000001	Power cable 2M	No	
ED4508-SP-22	AA007000038	Chuck Key	No	

ED4508






21



1

1



0

1

2



