


Spare Part No.	Part No.	Part Name	Easy Damage	Part Picture
PDB15006-SP-1	AA023000001	Hammer rod protector	No	
PDB15006-SP-1-19	AA023000575	Front cover sets	No	
PDB15006-SP-2	AA023000002	Protective lining	No	
PDB15006-SP-3	AA023000003	30 Retaining Ring	No	
PDB15006-SP-4	AA023000004	Support patch	No	
PDB15006-SP-5	AA023000005	Shock absorption ring	No	
PDB15006-SP-6	AA023000006	Move limited ring	No	

PDB15006-SP-7	AA023000007	Insert block	No	
PDB15006-SP-8	AA023000008	Change plate	No	
PDB15006-SP-9	AA023000009	Support ring spring	No	
PDB15006-SP-10	AA023000010	Support Ring	No	
PDB15006-SP-11	AA023000011	Move limited ring	No	
PDB15006-SP-12	AA023000012	6.5 Steel Ball	No	
PDB15006-SP-13	AA023000013	Hex. Socket Bolt M8×30(12.9)	No	
PDB15006-SP-13A	AA023000014	8 Spring Washer	No	
PDB15006-SP-14	AA023000015	Flange cover	No	


PDB15006-SP-15	AA023000016	O-Ring 63.5×2.6	No	
PDB15006-SP-16	AA023000017	Hammer rod sleeve	No	
PDB15006-SP-17	AA023000018	Fluorin O Ring 31.6×2.6	No	
PDB15006-SP-18	AA023000019	41 Retaining Ring	No	
PDB15006-SP-19	AA023000020	Oil Seal Ring 32×42×7	No	
PDB15006-SP-20	AA023000021	Impact Pin	No	
PDB15006-SP-21	AA023000022	Fluorin O Ring22×11	No	
PDB15006-SP-22	AA023000023	Control plate	No	

PDB15006-SP-23	AA023000024	Fixed Distance Sleeve	No	
PDB15006-SP-24	AA023000025	O-Ring $\Phi 35 \times \Phi 3$	No	
PDB15006-SP-25	AA023000026	Impact block	No	
PDB15006-SP-26	AA023000027	Fluorin O Ring $\Phi 30.4 \times \Phi 5$	No	
PDB15006-SP-27	AA023000028	Cover	No	
PDB15006-SP-28	AA023000029	Control Sleeve	No	
PDB15006-SP-29	AA023000030	Control Sleeve Spring	No	
PDB15006-SP-30	AA023000031	Cylinder	No	
PDB15006-SP-31	AA023000032	Piston Pin 10 $\times$ 38	No	


PDB15006-SP-32	AA023000033	Piston	No	
PDB15006-SP-33	AA023000034	Connecting Rod Ass'y	No	
PDB15006-SP-34-OLD	AA023000035	Impact body	No	
PDB15006-SP-45-NEW	DD00003087	Needle Ferrule	No	
PDB15006-SP-34-NEW	DD00003083	Impact body	No	
PDB15006-SP-34/42-45	DD00003198	Impact body Assy	No	
PDB15006-SP-35	AA023000036	Tapping screw ST6.3X32	No	
PDB15006-SP-36	AA023000037	Oil Tank Cover	No	
PDB15006-SP-37	AA023000038	Rubber Washer $\Phi 31 \times \Phi 25 \times 1$	No	
PDB15006-SP-38	AA023000039	Felt Ring	No	
PDB15006-SP-39	AA023000040	Hex .Socket BoltM5×12	No	


PDB15006-SP-40	AA023000041	Shell cover	No	
PDB15006-SP-41	AA023000042	O-Ring79×2.8	No	
PDB15006-SP-42-OLD	AA023G00043	Eccentric gear subassembl	No	
PDB15006-SP-42-NEW	DD00003084	Eccentric gear subassembl	No	
PDB15006-SP-43-OLD	AA023000044	Bearing 6002	No	
PDB15006-SP-43-NEW	DD00003085	Boring washer	No	
PDB15006-SP-44-OLD	AA023000045	Spacer sleeve	No	
PDB15006-SP-44-NEW	DD00003086	Needle Bearing RMAO16×22	No	
PDB15006-SP-45-OLD	AA023000046	Needle Ferrule	No	

PDB15006-SP-46	AA023000047	Needle Bearing Nk20×28×13	No	
PDB15006-SP-47	AA023000048	Seal ring subassembly	No	
PDB15006-SP-48	AA023000049	Housing Ass'y	No	
PDB15006-SP-49	AA023000050	Cord Clip	No	
PDB15006-SP-50	AA023000051	ST4.2×18 Tapping Screw	No	
PDB15006-SP-52	AA023000052	Main Handle Cover	No	
PDB15006-SP-54	AA023000053	Indicator	No	
PDB15006-SP-55	AA023000054	Main Handle	No	

PDB15006-SP-56	AA023000055	ST5.5×45 Tapping Screw	No	
PDB15006-SP-58	AA023000056	Cord Armor	No	
PDB15006-SP-59-F	A1002000001	Power cable 2M	No	
PDB15006-SP-59	DD00003006	Power cord	No	
PDB15006-SP-60	AA023000057	0.18μH Electricity Feels	No	
PDB15006-SP-61	AA023000058	Rivet	No	
PDB15006-SP-62	AA023S00059	Stator 220-240V	No	
PDB15006-SP-63	AA023000060	ST4.8×58 Tapping Screw	No	
PDB15006-SP-64	AA023000061	Carbon Brush bracket	No	
PDB15006-SP-65	AA023000062	Helical Spring	No	

PDB15006-SP-66	AA023000063	Metal contact plate	No	
PDB15006-SP-67	AA023000064	Tapping screw ST3.5X16	No	
PDB15006-SP-68	AA023000065	Metal insert	No	
PDB15006-SP-69	AA023C00066	Carbon Brush	No	
PDB15006-SP-70	AA023000067	Carbon Brush Wire	No	
PDB15006-SP-71	AA023000068	Screw seal ring	No	
PDB15006-SP-72	AA023R00069	Rotor	No	
PDB15006-SP-73	AA023000070	Bearing Sleeve	No	

PDB15006-SP-74	A1016200000	6200RS bearing	No	
PDB15006-SP-74A	AA023000071	10 Retaining Ring	No	
PDB15006-SP-75	AA023000072	O-Ring 30×2	No	
PDB15006-SP-76	AA023000073	Screw ring	No	
PDB15006-SP-77	AA023000074	Protected cover	No	
PDB15006-SP-78	AA023000075	Bearing Cover	No	
PDB15006-SP-79	AA023000076	Tapping screw ST5.5X25	No	
PDB15006-SP-80	AA023000077	Disk With Gap	No	

PDB15006-SP-80-87	DD00004415	Auxiliary handle assembly	No	
PDB15006-SP-80/81/83/84	DD00003710	Side Handle Assy	No	
PDB15006-SP-81	AA023000078	Clamping	No	
PDB15006-SP-81-NEW	AA023000078	Clamping	No	
PDB15006-SP-82	AA023000079	Fixed Belt	No	
PDB15006-SP-83	AA023000080	Hexagon Head Bolt M8×130	No	
PDB15006-SP-84	AA023000081	Side Handle	No	
PDB15006-SP-85	AA023000082	Function Knob	No	
PDB15006-SP-86	AA023000083	Nut M8(Thickness 6.4Mm)	No	

PDB15006-SP-87	AA023000084	Function Knob Cover	No	
PDB15006-SP-88	AA023000085	10mm Hex Bar Wrench	No	
PDB15006-SP-89	AA023000086	Dual Screw Driver	No	
PDB15006-SP-91	DD00003275	Oil BottleΦ35×135	No	
PDB15006-SP-92	AA023000088	Fixed Platen	No	
PDB15006-SP-93	AA023000089	Main Handle Seat	No	
PDB15006-SP-94	AA023000090	Shock Absorption Jacket	No	
PDB15006-SP-95	AA023000091	Shock Absorption Ferrule	No	
PDB15006-SP-96	AA023000092	Shock Absorption Spring	No	

PDB15006-SP-97	AA023000093	Spring Rack	No	
PDB15006-SP-98	AA023000094	Cross recessed pan head screw	No	
PDB15006-SP-99	AA023000095	O-Ring $\Phi 16 \times \Phi 3$	No	
PDB15006-SP-101	AA023000096	Speed Adjuster	No	
PDB15006-SP-102	AA023W00097	Switch	No	

