



| Spare Part No.   | Part No.    | Part Name                | Easy Damage | Part Picture                                                                          |
|------------------|-------------|--------------------------|-------------|---------------------------------------------------------------------------------------|
| PDB130018-SP-1   | DD00005677  | Circlip 28               | No          |    |
| PDB130018-SP-1-6 | DD00006087  | Head assembly (assembly) | No          |    |
| PDB130018-SP-2   | DD00005678  | Locating ring            | No          |    |
| PDB130018-SP-3   | DD00005679  | Sliding lock sleeve      | No          |   |
| PDB130018-SP-4   | DD00005680  | Spring 31x2x29           | No          |  |
| PDB130018-SP-5   | DD00005681  | Steel ball 7.938         | No          |  |
| PDB130018-SP-6   | DD00005682  | Steel head               | No          |  |
| PDB130018-SP-7   | AA023000517 | screw M8*35/washer8      | No          |                                                                                       |
| PDB130018-SP-8   | DD00005683  | Hammer G0845M            | No          |  |

|                    |             |                             |    |                                                                                       |
|--------------------|-------------|-----------------------------|----|---------------------------------------------------------------------------------------|
| PDB130018-SP-9     | DD00005684  | Stop washer 39.8x27.5x5     | No |    |
| PDB130018-SP-10    | DD00005685  | Washer                      | No |    |
| PDB130018-SP-11    | DD00005686  | O-ring 26.3X4               | No |    |
| PDB130018-SP-12    | DD00005687  | Cylinder G0845M             | No |    |
| PDB130018-SP-13    | DD00005688  | Aluminum barrel             | No |    |
| PDB130018-SP-14    | DD00005689  | Paper washer DG0845K        | No |                                                                                       |
| PDB130018-SP-15    | DD00005690  | HammerG0845M                | No |    |
| PDB130018-SP-16    | DD00005691  | O-ring 28.4X3.5             | No |   |
| PDB130018-SP-17    | AA023000475 | piston pin                  | No |                                                                                       |
| PDB130018-SP-18    | AA023000476 | piston                      | No |                                                                                       |
| PDB130018-SP-19/20 | AA023000477 | needling bearing/connecting | No |                                                                                       |
| PDB130018-SP-21-25 | AA023000478 | oil cover                   | No |                                                                                       |
| PDB130018-SP-26    | AA023000491 | O-ring 48*2.2               | No |                                                                                       |
| PDB130018-SP-27    | AA023000525 | eccentric shaft             | No |                                                                                       |
| PDB130018-SP-28    | DD00005692  | Key \3.9*12                 | No |  |
| PDB130018-SP-29    | DD00005693  | Circlip 47                  | No |  |
| PDB130018-SP-30    | AA023000527 | bearing 6303-RS             | No |                                                                                       |
| PDB130018-SP-31    | AA023000528 | O-Ring 46.2*2               | No |                                                                                       |
| PDB130018-SP-32    | DD00005694  | Gear box YH45               | No |                                                                                       |
| PDB130018-SP-33    | AA023000530 | position sleeve             | No |                                                                                       |
| PDB130018-SP-34    | AA023000531 | oil seal FB22*30*6          | No |                                                                                       |

|                 |             |                             |    |                                                                                       |
|-----------------|-------------|-----------------------------|----|---------------------------------------------------------------------------------------|
| PDB130018-SP-35 | DD00005695  | Gear                        | No |    |
| PDB130018-SP-36 | A1016001000 | Ball Bearing 6001/C3-Zrs    | No |                                                                                       |
| PDB130018-SP-37 | DD00005696  | Gear box cover              | No |                                                                                       |
| PDB130018-SP-38 | AA023000533 | anti-oil washer 0810C       | No |                                                                                       |
| PDB130018-SP-39 | A1016201000 | Bearing 6201                | No |                                                                                       |
| PDB130018-SP-40 | AA023000535 | Bearing Board               | No |                                                                                       |
| PDB130018-SP-41 | AA023000536 | Flat /Spring Washer4 /Screw | No |                                                                                       |
| PDB130018-SP-43 | DD00005697  | Rotor                       | No |    |
| PDB130018-SP-44 | AA023000556 | Washer8.1*21*0.5            | No |                                                                                       |
| PDB130018-SP-45 | A1010608000 | Bearing 608                 | No |                                                                                       |
| PDB130018-SP-46 | AA000000074 | fan guide                   | No |                                                                                       |
| PDB130018-SP-47 | AA023000537 | Screw ST4.8*58              | No |  |
| PDB130018-SP-48 | DD00005698  | Stator 0845K-30             | No |  |
| PDB130018-SP-49 | DD00005699  | Motor housing YH0845        | No |  |
| PDB130018-SP-50 | AA023000539 | flat /spring washer6 /screw | No |                                                                                       |
| PDB130018-SP-51 | DD00005700  | Carbon brush holder 6.5*11  | No |  |
| PDB130018-SP-52 | DD00005500  | Carbon Brush                | No |  |

|                    |             |                           |    |                                                                                       |
|--------------------|-------------|---------------------------|----|---------------------------------------------------------------------------------------|
| PDB130018-SP-53    | DD00005702  | Coil spring               | No |    |
| PDB130018-SP-54    | DD00005703  | Screw ST3.9*10            | No |                                                                                       |
| PDB130018-SP-55    | DD00005704  | Motor cover YH0845        | No |    |
| PDB130018-SP-56    | DD00005705  | Screw ST3.9*16            | No |                                                                                       |
| PDB130018-SP-57    | AA023000541 | Screw M8*50               | No |                                                                                       |
| PDB130018-SP-58/70 | DD00005706  | Left Handle /Right Handle | No |                                                                                       |
| PDB130018-SP-59    | AA023000543 | anti-vibration sleeve     | No |                                                                                       |
| PDB130018-SP-60    | AA023000544 | anti-vibration spring     | No |                                                                                       |
| PDB130018-SP-61    | AA023000545 | Anti-vibration board      | No |                                                                                       |
| PDB130018-SP-62    | AA023000546 | Anti-Vibration Screwm8*35 | No |                                                                                       |
| PDB130018-SP-63    | DD00005707  | Switch button             | No |                                                                                       |
| PDB130018-SP-64    | DD00005708  | Spring                    | No |    |
| PDB130018-SP-65    | DD00005709  | Switch                    | No |   |
| PDB130018-SP-66    | DD00005710  | Capacitor 0.33μF          | No |  |
| PDB130018-SP-67    | AA021000292 | Cable Board               | No |                                                                                       |
| PDB130018-SP-68    | DD00005711  | Cord Guard                | No |  |
| PDB130018-SP-69    | AA023000547 | Cable 2X1Mm2 2M           | No |                                                                                       |
| PDB130018-SP-71    | AA023000548 | Nut M8                    | No |  |
| PDB130018-SP-72    | AA023000550 | rotary knob               | No |                                                                                       |

|                 |             |                  |    |                                                                                     |
|-----------------|-------------|------------------|----|-------------------------------------------------------------------------------------|
| PDB130018-SP-73 | AA023000551 | auxiliary handle | No |                                                                                     |
| PDB130018-SP-75 | AA023000552 | knob set         | No |  |
| PDB130018-SP-76 | AA023000553 | clamp set        | No |                                                                                     |
| PDB130018-SP-77 | DD00005712  | Hose clamp       | No |  |

